

AEG

Pushbuttons



Pushbutton Type Operators - Non-Illuminated



Style	Colour Type	Metal	Polyamide
		Part Number	Part Number
Flush	Black	BMD-GS	BFD-GS
	Red	BMD-GR	BFD-GR
	Green	BMD-GG	BFD-GG
	Yellow	BMD-GY	BFD-GY
	Blue	BMD-GB	BFD-GB
	White	BMD-GW	BFD-GW
Raised	Black	BMD-SS	BFD-SS
	Red	BMD-SR	BFD-SR
	Green	BMD-SG	BFD-SG
	Yellow	BMD-SY	BFD-SY
	Blue	BMD-SB	BFD-SB
	White	BMD-SW	BFD-SW
Recessed	Black	BMD-ES	BFD-ES
	Red	BMD-ER	BFD-ER
	Green	BMD-EG	BFD-EG
	Yellow	BMD-EY	BFD-EY
	Blue	BMD-EB	BFD-EB
	White	BMD-EW	BFD-EW

Mushroom Type Operators (Momentary) - Non-Illuminated






Style	Colour Type	Metal	Polyamide
		Part Number	Part Number
Momentary 28mm Head	Black	BMP-3S	BFP-3S
	Red	BMP-3R	BFP-3R
	Green	BMP-3G	BFP-3G
	Yellow	BMP-3Y	BFP-3Y
Momentary 40mm Head	Black	BMP-4S	BFP-4S
	Red	BMP-4R	BFP-4R
	Green	BMP-4G	BFP-4G
	Yellow	BMP-4Y	BFP-4Y
Momentary 60mm Head	Black	BMP-5S	BFP-5S
	Red	BMP-5R	BFP-5R
	Green	BMP-5G	BFP-5G
	Yellow	BMP-5Y	BFP-5Y

AEG



Pushbuttons



Pushbutton Type Operators - Illuminated

Style	Colour Type	Metal	Polyamide
		Part Number	Part Number
 Flush	Clear	BML-GC	BFL-GC
	Red	BML-GR	BFL-GR
	Green	BML-GG	BFL-GG
	Yellow	BML-GY	BFL-GY
	Blue	BML-GB	BFL-GB
	White	BML-GW	BFL-GW
 Raised	Clear	BML-SC	BFL-SC
	Red	BML-SR	BFL-SR
	Green	BML-SG	BFL-SG
	Yellow	BML-SY	BFL-SY
	Blue	BML-SB	BFL-SB
	White	BML-SW	BFL-SW
 Recessed	Clear	BML-EC	BFL-EC
	Red	BML-ER	BFL-ER
	Green	BML-EG	BFL-EG
	Yellow	BML-EY	BFL-EY
	Blue	BML-EB	BFL-EB
	White	BML-EW	BFL-EW

Mushroom Type Operators - Illuminated

Style	Colour Type	Metal	Polyamide
		Part Number	Part Number
 Momentary	Red	BMP-4RL	BFP-4RL
	Green	BMP-4GL	BFP-4GL
	Yellow	BMP-4YL	BFP-4YL
	Blue	BMP-4BL	BFP-4BL
	White	BMP-4WL	BFP-4WL
 Maintained	Red	BML-PR	BFL-PR
	Green	BML-PG	BFL-PG
	Yellow	BML-PY	BFL-PY
	Blue	BML-PB	BFL-PB
	White	BML-PW	BFL-PW

Dual Start/Stop Operators - Illuminated or Non-Illuminated

Style	Colour Type	Metal	Polyamide
		Part Number	Part Number
Momentary	Red & Green	-	BSD-L01



AEG

Pushbuttons



Selector Switch Type Operators - Non-Illuminated

Style	Colour Type	Metal	Polyamide
		Part Number	Part Number
2 Position Maintained	Black	BMK-1S	BFK-1S
	Red	BMK-1R	BFK-1R
	Green	BMK-1G	BFK-1G
	Yellow	BMK-1Y	BFK-1Y
	Blue	BMK-1B	BFK-1B
2 Position Momentary	Black	BMK-2S	BFK-2S
	Red	BMK-2R	BFK-2R
	Green	BMK-2G	BFK-2G
	Yellow	BMK-2Y	BFK-2Y
	Blue	BMK-2B	BFK-2B
3 Position Maintained	Black	BMK-3S	BFK-3S
	Red	BMK-3R	BFK-3R
	Green	BMK-3G	BFK-3G
	Yellow	BMK-3Y	BFK-3Y
	Blue	BMK-3B	BFK-3B
3 Position Momentary Left-> Center	Black	BMK-4S	BFK-4S
	Red	BMK-4R	BFK-4R
	Green	BMK-4G	BFK-4G
	Yellow	BMK-4Y	BFK-4Y
	Blue	BMK-4B	BFK-4B
3 Position Momentary Right-> Center	Black	BMK-5S	BFK-5S
	Red	BMK-5R	BFK-5R
	Green	BMK-5G	BFK-5G
	Yellow	BMK-5Y	BFK-5Y
	Blue	BMK-5B	BFK-5B
3 Position Momentary Both-> Center	Black	BMK-6S	BFK-6S
	Red	BMK-6R	BFK-6R
	Green	BMK-6G	BFK-6G
	Yellow	BMK-6Y	BFK-6Y
	Blue	BMK-6B	BFK-6B
4 Position Maintained	Black	BMK-7S	BFK-7S
5 Position Maintained	Black	BMK-8S	BFK-8S





AEG

Pushbuttons



Selector Switch Type Operators - Illuminated

Style	Colour Type	Metal	Polyamide
		Part Number	Part Number
2 Position Maintained	Red	BML-2R	BFL-2R
	Green	BML-2G	BFL-2G
	Yellow	BML-2Y	BFL-2Y
	Blue	BML-2B	BFL-2B
	White	BML-2W	BFL-2W
2 Position Momentary	Red	BML-2RM	BFL-2RM
	Green	BML-2GM	BFL-2GM
	Yellow	BML-2YM	BFL-2YM
	Blue	BML-2BM	BFL-2BM
	White	BML-2WM	BFL-2WM
3 Position Maintained	Red	BML-3R	BFL-3R
	Green	BML-3G	BFL-3G
	Yellow	BML-3Y	BFL-3Y
	Blue	BML-3B	BFL-3B
	White	BML-3W	BFL-3W
3 Position Momentary Left-> Center	Red	BML-3RL	BFL-3RL
	Green	BML-3GL	BFL-3GL
	Yellow	BML-3YL	BFL-3YL
	Blue	BML-3BL	BFL-3BL
	White	BML-3WL	BFL-3WL
3 Position Momentary Right-> Center	Red	BML-3RR	BFL-3RR
	Green	BML-3GR	BFL-3GR
	Yellow	BML-3YR	BFL-3YR
	Blue	BML-3BR	BFL-3BR
	White	BML-3WR	BFL-3WR
3 Position Momentary Both-> Center	Red	BML-3RC	BFL-3RC
	Green	BML-3GC	BFL-3GC
	Yellow	BML-3YC	BFL-3YC
	Blue	BML-3BC	BFL-3BC
	White	BML-3WC	BFL-3WC



AEG

Pushbuttons



Selector Switch Type Operators - Key Type

Style	Key Removal	Metal	Polyamide
		Part Number	Part Number
2 Position Maintained	Both	BMS-OK	BFS-OK
	Left	BMS-OA	BFS-OA
	Right	BMS-OE	BFS-OE
2 Position Momentary	Left	BMS-OT	BFS-OT
3 Position Maintained	Both	BMS-OM	BFS-OM
3 Position Momentary Left-> Center	Center	BMS-OS	BFS-OS
3 Position Momentary Right-> Center	Center	BMS-2S	BFS-2S
3 Position Momentary Both-> Center	Center	BMS-4R	BFS-4R
4 Position Maintained	Left	BMS-1V	BFS-1V



Joystick Type Operators

Style	Type	Metal	Polyamide
		Part Number	Part Number
3 Position	Maintained	BMN-2F	BFN-2F
3 Position	Momentary	BMN-2T	BFN-2T
5 Position	Maintained	BMN-4F	BFN-4F
5 Position	Momentary	BMN-2T	BFN-2T



2x SEU11 Contact Blocks are required per joystick operators

AEG

Pushbuttons



Pilot Light Type Operators



Style	Colour	Metal	Polyamide
		Part Number	Part Number
Lens & Cap Bulb Holder Required	Red	BML-KR	BFL-KR
	Green	BML-KG	BFL-KG
	Yellow	BML-KY	BFL-KY
	Blue	BML-KB	BFL-KB
	White	BML-KW	BFL-KW
	Clear	BML-KC	BFL-KC
	Unibloc All in One (Bulb Sold Seperately)	Red	-
Green		-	P9XUVDD0
Yellow		-	P9XUGDD0
Blue		-	P9XULDD0
Orange		-	P9XUADD0
White		-	P9XUBDD0
Clear		-	P9XUIDD0

Accessories



Style	Configuration	Type	Part Number
Contact Block	1NO	-	SES10
	1NC	-	SES01
	1NO1NC	-	SEU11
	2NO	-	SEU20
	2NC	-	SEU02
	1NO	Early Make	SEV10
	1NC	Late Break	SEV01
Bulb Holder	-	BA9 - Bulb Holder	BLN-VO
Bulb & Holder	All in One	LED - 24VAC/DC - Green	BLL-VND-G
		LED - 120VAC - Green	BLL-VNJ-G
		LED - 24VAC/DC - Red	BLL-VND-R
		LED - 120VAC - Red	BLL-VNJ-R
Bulbs	Red	LED	BA9S**LEDR
	Green	LED	BA9S**LEDV
	Yellow	LED	BA9S**LEDG
	Blue	LED	BA9S**LEDL
	White	LED	BA9S**LEDB

** - Replace with "24" for 24VAC/DC, "110" for 110VAC or "230" for 230VAC